



# Waveline Dolphin C

WLM-DOLPHIN-C



\*Shown with optional CA605 case & lighting



## PARTS INCLUDED

**Straight Poles:** (4)WLM#10  
(4)WLM#05  
(2)WLM#37  
(4)WLM#17  
(2)WLM#34



(4) Soft Bag

**Corner Poles:** (4)WLM#90  
(4)WLM#35  
(4)WLM#16



**Feet:**



(2) Single Edge Feet  
WLM#22E



(1) Double Left Feet With Necking  
WLM#22L



**Clear Double C Clamps**  
(4)WLM#24L-CLEAR  
(4)WLM#24R-CLEAR



(1) Double U-Shaped Clamp  
WLM#27



(4) Fabric Graphics



## DISPLAY CONSTRUCTION

Aluminum frame with aluminum support feet

## LIMITED WARRANTY PERIODS

- Frame : Lifetime

## GRAPHIC MATERIAL & FINISHING

Top grade YKK zippers along bottom of display.  
Dye sublimated on One Planet, 100% recycled, fabric


Bottles recycled

**368**


## DIMENSIONS

|                |                                       |
|----------------|---------------------------------------|
| Assembled Unit | 225.8"w x 104.6"h                     |
| Graphic Size   | (2) 116.2"w x 88.9"h (2) 102"w x 14"h |
| Shipping Box   | (4) 36"w x 14"h x 14"d, 56 lbs total  |


Waveline Dolphin C  
WLM-DOLPHIN-C




- ① Lay out parts according to the assembly diagram and push the pipes together. Insert center suport pole.




- ② Feed the fabric from the top of the frame, only a few feet at a time. Close the zipper.




- ③ Set up the feet in the position that you want to erect the stand, lift the panel(s) and fit on the feet.



- ④ To lock the frames together, use the "S" shaped clamp. If you have a header in the kit you can fix to the top by using the clear plastic clips.



- ⑤ Attach the header using the clips to the display banner.



- ⑥ For optional lights, position as desired and clamp into place.

| WLM-DOLPHIN-C |               |
|---------------|---------------|
| QTY           | PART NUMBER   |
| 4             | WLM#35        |
| 4             | WLM#23        |
| 2             | WLM#22E       |
| 1             | WLM#22L       |
| 1             | WLM#27        |
| 4             | WLM#24L-CLEAR |
| 4             | WLM#24R-CLEAR |
| 4             | WLM#10        |
| 4             | WLM#05        |
| 4             | WLM#90        |
| 2             | WLM#37        |
| 4             | WLM#17        |
| 4             | WLM#16        |
| 2             | WLM#34        |